

# S u H i M a r

SUMINISTROS HIDRAULICOS



**RACORERIA**  
**ROSCA SAE - JIC**

**TUERCA**



**Rosca**

**7/16**  
1/2  
**9/16**  
3/4  
**7/8**  
1"1/16  
**1"5/16**

**CONO DE CIERRE**



**Medida**

**Tubo**

7/16 **6mm**  
**1/2** 8mm  
9/16 **10mm**  
**3/4** 12mm  
7/8 **16mm**  
**1"1/16** 20mm  
1"5/16 **25mm**

**EMPALME MACHO  
SAE (JIC)**



**Rosca 1    Rosca 2**

**7/16**    7/16  
**1/2**    1/2  
**9/16**    9/16  
**3/4**    3/4  
**7/8**    7/8  
**1"1/16**    1"1/16  
**1"5/16**    1"5/16  
**1"5/8**    1"5/8  
**1"7/8**    1"7/8

**EMPALME MACHO  
SAE(JIC) - UNF**



**Rosca  
SAE(JIC)    Rosca  
UNF**

**7/16**    7/16  
**7/16**    1/2  
**7/16**    9/16  
**1/2**    1/2  
**9/16**    9/16  
**9/16**    3/4  
**3/4**    3/4  
**3/4**    7/8  
**3/4**    1"1/16  
**7/8**    3/4  
**7/8**    7/8  
**7/8**    1"1/16  
**1"1/16**    3/4  
**1"1/16**    7/8  
**1"1/16**    1"1/16  
**1"1/16**    1"5/16  
**1"5/16**    1"1/16  
**1"5/16**    **1"5/16**



**ADAPTADOR  
MACHO - HEMBRA  
SAE(JIC)-GAS(BSP)**



Rosca Macho SAE	Rosca Hembra GAS
7/16	<b>1/8</b>
<b>7/16</b>	1/4
1/2	<b>1/4</b>
<b>9/16</b>	3/8
3/4	<b>3/8</b>
<b>3/4</b>	1/2
7/8	<b>1/2</b>
<b>1"1/16</b>	3/4
<b>1"5/16</b>	1"
<b>1"5/8</b>	1"1/4
<b>1"7/8</b>	1"1/2

**TUERCA CIEGA**



Rosca
7/16
<b>1/2</b>
9/16
<b>3/4</b>
7/8
<b>1"1/16</b>
1"5/16

**TAPON MACHO**



Rosca
<b>7/16</b>
1/2
<b>9/16</b>
3/4
<b>7/8</b>
1"1/16
<b>1"5/16</b>

**ADAPTADOR  
MACHO FIJO  
TUERCA LOCA  
SAE(JIC)-GAS(BSP)**



Rosca Hembra SAE	Rosca Macho GAS
7/16	<b>1/4</b>
<b>1/2</b>	1/4
9/16	<b>1/4</b>
<b>9/16</b>	3/8
3/4	<b>3/8</b>
<b>3/4</b>	1/2
7/8	<b>1/2</b>
1"1/16	<b>3/4</b>
1"5/16	<b>3/4</b>
1"5/16	<b>1"</b>

PASATABIQUES



Rosca

7/16  
1/2  
9/16  
3/4  
7/8  
1"1/16  
1"5/16

ADAPTADOR  
TUERCA LOCA



Rosca 1 Rosca 2

7/16 7/16  
1/2 1/2  
9/16 9/16  
3/4 3/4  
7/8 7/8  
1"1/16 1"1/16  
1"5/16 1"5/16

CODO 90  
MACHO FIJO



Rosca 1 Rosca 2

7/16 7/16  
1/2 1/2  
9/16 9/16  
3/4 3/4  
7/8 7/8  
1"1/16 1"1/16  
1"5/16 1"5/16  
1"5/8 1"5/8

CODO 90°  
MACHO ORIENTABLE  
SAE(JIC)-GAS(BSP)



Rosca SAE Rosca GAS

7/16 1/8  
7/16 1/4  
1/2 1/4  
9/16 1/4  
9/16 3/8  
3/4 1/4  
3/4 3/8  
3/4 1/2  
7/8 3/8  
7/8 1/2  
7/8 3/4  
1"1/16 1/2  
1"1/16 3/4  
1"5/16 3/4  
1"5/16 1"  
1"5/16 1"1/4  
1"5/8 1"  
1"5/8 1"1/4

CODO 90°  
MACHO ORIENTABLE  
SAE (JIC)



Rosca 1 Rosca 2

7/16 7/16  
1/2 1/2  
9/16 9/16  
3/4 3/4  
7/8 7/8  
1"1/16 1"1/16  
1"5/16 1"1/16  
1"5/16 1"5/16

**CODO 90°  
MACHO ORIENTABLE  
SAE(JIC)-METRICO**



Rosca SAE	Rosca METRICA
7/16	10x100
1/2	12x150
9/16	14x150
3/4	16x150
3/4	18x150
7/8	18x150
7/8	22x150

**CODO 90°  
MACHO FIJO  
TUERCA LOCA**



Rosca Macho	Rosca Hembra
7/16	7/16
1/2	1/2
9/16	9/16
3/4	3/4
7/8	7/8
1"1/16	1"1/16
1"5/16	1"5/16
1"5/8	1"5/8

**CODO 90°  
MACHO FIJO  
SAE(JIC)-GAS(NPT)**



Rosca SAE	Rosca GAS
7/16	1/8
7/16	1/4
1/2	1/4
9/16	1/4
3/4	3/8
3/4	1/2
7/8	1/2

**CODO 45°  
MACHO FIJO  
TUERCA LOCA**



Rosca Macho	Rosca Hembra
7/16	7/16
1/2	1/2
9/16	9/16
3/4	3/4
7/8	7/8
1"1/16	1"1/16
1"5/16	1"5/16

**TE  
MACHO FIJO**



Rosca 1	Rosca 2	Rosca 3
7/16	7/16	7/16
1/2	1/2	1/2
9/16	9/16	9/16
3/4	3/4	3/4
7/8	7/8	7/8
1"1/16	1"1/16	1"1/16
1"5/16	1"5/16	1"5/16

**TE  
MACHO FIJO  
ORIENTABLE  
LATERAL**



Rosca 1	Rosca 2	Rosca 3
7/16	7/16	7/16
1/2	1/2	1/2
9/16	9/16	9/16
3/4	3/4	3/4
7/8	7/8	7/8
1"1/16	1"1/16	1"1/16

TE  
TUERCA LOCA  
CENTRAL



Rosca 1	Rosca 2	Rosca 3
7/16	<b>7/16</b>	7/16
1/2	<b>1/2</b>	1/2
9/16	<b>9/16</b>	9/16
3/4	<b>3/4</b>	3/4
7/8	<b>7/8</b>	7/8
1"1/16	<b>1"1/16</b>	1"1/16
1"5/16	<b>1"5/16</b>	1"5/16

TE  
TUERCA LOCA  
LATERAL



Rosca 1	Rosca 2	Rosca 3
<b>7/16</b>	7/16	<b>7/16</b>
<b>1/2</b>	1/2	<b>1/2</b>
<b>9/16</b>	9/16	<b>9/16</b>
<b>3/4</b>	3/4	<b>3/4</b>
<b>7/8</b>	7/8	<b>7/8</b>
<b>1"1/16</b>	1"1/16	<b>1"1/16</b>
<b>1"5/16</b>	1"5/16	<b>1"5/16</b>